Dr. Fixit Fastflex



HIGH PERFORMANCE POLYMER MODIFIED CEMENTITIOUS COATING

Description

Dr. Fixit Fastflex is a two component cementitious coating system for waterproofing of wet areas and any water retaining structures such as swimming pools and water features. It provides strong bonding and excellent resistant to hydrostatic water pressure by forming highly elastic seamless coating over the applied concrete surfaces.

Typical Applications

- Any concrete, cement or masonry surface that are subject to moisture ingress.
- Swimming pools, water features and water tanks.
- Bathrooms, toilets, balconies, planters etc.

Features

- Seamless, impervious membrane.
- Elastomeric.
- High film build-up.
- Excellent adhesion to concrete and masonry substrates.
- Low VOC.
- Easily applied by brush, roller or trowel.
- Can be applied on damp surfaces.

Packaging

12 kg and 48 kg

Method of Application

1 SURFACE PREPARATION

- The surface of application must be thoroughly prepared by mechanical means, to remove all loose particles, laitance, etc.
- Oil and grease, if any, must be de-greased with suitable solvents. It then must be washed off with jet of water and brought to touch dry state.
- Any surface undulations, cracks and crevices must be duly filled or repaired with cement sand mortar mixed with latex polymers such as Dr. Fixit Pidicrete URP.
- All vertical up-stands & junctions /corners are provided with 45° fillet with Polymer Modified Mortar (PMM), mixed with Dr. Fixit Pidicrete URP all around the periphery of the junction.
- Substrate must be in a "Saturated Surface Dry" (SSD) condition (damp, without standing water) prior to application.

2 MIXING

- Using a slow speed mechanical mixer and a clean suitable mixing vessel, slowly add the powder component to the liquid polymer and stir until a smooth and homogenous slurry, is achieved.
- Allow the mixed slurry to stand for 5 10 minutes before use.
- Do not dilute with water.

3 APPLICATION

- All the pipe inserts or sanitary fittings should have been fitted grouted with suitable products from the Dr. Fixit range well before taking up the application.
- Grout pipe inserts using Dr Fixit Bathseal Tape and Dr Fixit Bathseal Grout or a suitable non shrink grout.



- It is mandatory that all works of plumbing and sanitation must be complete before taking up application of Dr. Fixit Fastflex.
- The surface of application must be pre-wetted thoroughly with water & brought to a touch dry state. Take up the first coat application with a stiff nylon brush. Work well into the substrate, to ensure that all small undulations are completely filled with the coating.
- Provide and lay 50 gsm glass fibre mesh over the angle fillet when the first coat in still wet.
- 6 to 8 hrs after completion of first coat, take up second coat application in a direction perpendicular to the first.
- Complete the application and leave to air cure for 3-5 days. A moist hessian cloth can be kept over the coated surface to protect it from the effect of direct sunlight, in case of bathrooms and internal areas, leave the coating without water curing for 3-5 days at least.
- In new bathrooms, typically, Dr. Fixit Fastflex must be applied all over the sunken slab portion and upwards over the masonry walls up to a height of 6-7 feet, i.e. Over the splash zone of shower, etc. to ensure complete waterproofing.
- For vertical walls in bathroom ensure internal plaster is sound, levelled and mixed with Dr. Fixit Pidiproof LW+, Apply 2 coats of Dr. Fixit Fastflex on all over or shower area, sprinkle the coarse, quartz sand while the second coat is still wet. This will provide key for subsequent tile adhesive materials.

4 GENERAL WATERPROOFING AND WATERPROOFING OF WATER TANKS

- General waterproofing if applied in areas exposed to foot traffic, it must be protected with a screed overlaid, during the application itself.
- When coating for internal walls of water tanks, sprinkle coarse sand after second coat on wet coating to facilitate anchoring for upcoming protection plaster.

Precautions & Limitations

- Do not add water to Dr. Fixit Fastflex during application.
- Dr. Fixit Fastflex needs atleast 3-5 days days for water or moisture curing. Cure with help of moist hessian cloth.
- Do not cure by flooding with water or conduct any ponding test before it gets completely cured.
- Concrete & masonry surfaces must be cured for 28 days before application.
- Overlay of a cementitious screed must be done with 24 to 48 hrs. if applied in wet areas & bathrooms.
- Do not use on metal or wooden substrates, on bituminous coverings, to waterproof surfaces direct exposed to traffic and uncovered swimming pools.

Technical Information

PROPERTIES	TEST METHOD	RESULTS
Nature & Mixing ratio		2 component cementitous coating (1 part polymer & 1.4 part powder)
pH of the mix		>10.0
Pot life of the mix @30°C		60 minutes
Touch Dry Time	ASTM D 1640:2018	50 minutes
Inter coat application time		6-8 hrs
Cure time after 2 nd coat		3-5 days
Elongation at break	ASTM D 412:2016	120% minimum
Tensile Strength	ASTM D 412:2016	1.0 N/mm ²
Water Vapour Transmission	ASTM E 96:2016	0.7 Perms
Adhesion strength	ASTM D 7234:2019	0.8 N/mm ²



PROPERTIES	TEST METHOD	RESULTS
Crack bridging	EN 1062-7:2004	No cracking upto 2 mm
Water Permeability	EN 12390-8:2019	Passes 5 bar positive water pressure
Reduction in Rapid Chloride, %	ASTM C 1202:2019	70
Food grade certification	CFTRI certification	Passes

Theoretical Coverage*

The approximate coverage per pack at even consistency (DFT of 1.2-1.5 mm thickness) is as follows:

SKU	COVERAGE	
5 kg polymer + 7 kg Powder	5-6 m ²	
20 kg polymer + 28 kg Powder	20-24 m ²	

*Coverage may vary depending upon the nature and texture of the substrate

Shelf Life

Shelf life is 12 months from the date of manufacturing if stored in original and unopened packaging in a cool dry place away from direct sunlight.

Health and Safety

This product is a water based emulsion of non-hazardous polymer. It is nonflammable and essentially non toxic. Normal industrial hygiene procedures should be adhered to particularly when spraying and it is recommended that gloves and eye protection be worn. In case of skin or eye contact thoroughly irrigate with water and seek medical advice if any irritation develops or persists. In the case of accidental ingestion, wash mouth out with water and seek medical attention. Spillages should be cleaned up immediately with water as they will leave a film on evaporation. See MSDS for further information.

Other Products Categories available

Dr. Fixit brings you the widest range of Construction Chemicals





Pidilite Industries Limited Construction Chemicals Division Ramkrishna Mandir Road, Post Box No. 17411 Andheri (E) Mumbai 400059 INDIA Tel +91-22-2835 7000 · Fax +91-22-2835 7008 www.drfixit.co.in · info.drfixit@pidilite.com Dr. Fixit Advice Centre (Toll Free No.) 1800 209 5504 DISCLAIMER The product information & application details given by the company & its agents has been provided in good faith & meant to serve only as a general guideline during usage. Users are advised to carry out tests & take trials to ensure on the suitability of products meeting their requirement prior to full scale usage of our products. Since the correct identification of the problems, quality of other materials used and the on-site workmanship are factors beyond our control, there are no expressed or implied guarantee / warranty as to the results obtained. The company does not assume any liability or consequential damage for unsatisfactory results, arising from the use of our products.